

# TECH UPDATE

## REQUIRED OVERHANG EXTERIOR DOORS

For best performance and to meet the standard warranty, any exterior door should be installed under an overhang or with sufficient protection. Adequate overhang depends on typical weather conditions of the area where the door is installed, but at the minimum means an overhang projecting a distance from the structure equal to one half the distance between the bottom of the door and the bottom of the overhang.

